



INSTALLATION INSTRUCTION
FOR
C-2533 FOR WILLIAMS VALVE WITH RESERVOIR

HW-6 Kit
C-2533 Cylinder
V-55 Valve
TF-12 Tubing & Fitting

PREPARE VALVE

1. Make sure valve is free from all foreign particles.
2. Remove the end spring cover using 1" wrench.

PREPARE CYLINDER

1. Remove two 1/4" nuts from back of cylinder. This will disassemble cylinder into two parts:
 - a. Cylinder with two long cap screws
 - b. Spring cover with bracket
2. Remove pipe plug from rear of cylinder using 3/16" Allen wrench

MOUNTING CYLINDER ON VALVE

1. Install spring cover with bracket on valve using 1" wrench
2. Attach cylinder to valve by inserting 3/16" Allen wrench through the hole in the rear cover plate, tighten firmly
3. Push cylinder flush against spring cover. Attach with 1/4" nuts on each side of bracket. Rotate bracket and cylinder to desired position then tighten firmly against spring cover.
4. Reinstall pipe plug in rear of cylinder using a thread sealant
5. Install air lines and test for proper operation