



Air Power Systems Co., Inc.
8178 E. 44th St.
Tulsa, OK 74145
(918) 622-5600 FAX: (918) 622-5469

Installation Instructions WBR-3 Control Kit for Braden Winch NISU3-10FEB

Revision:)A, 02/22/2013
Approved By: Ken Thompson

Page 1 of 1

1. Push clutch lever arm all the way forward, making sure clutch is engaged.
2. Remove lever arm bracket from winch frame. Weld APSCO two-hole bracket to clutch lever arm after inserting clutch lever arm into second hole of bracket.
3. Align bracket on clutch lever arm and bracket on cylinder on the base angle and weld in place.

