

Resource Manual
Installation Guide • Operating Procedures • Parts Breakdown



MODEL 500P

HYDRAULIC COOLER & TANK STABILIZER

PROPANE USE ONLY



Serial #: _____

Installation Date: _____



INSTALLATION GUIDE, OPERATING PROCEDURES & PARTS BREAKDOWN

MODEL 500P

HYDRAULIC COOLER & TANK STABILIZER

PROPANE USE ONLY

INDEX

| <u>STEP</u> | <u>DESCRIPTION</u> | <u>PAGE</u> |
|-------------|-------------------------------|-------------|
| | Index | 1 |
| | Introduction | 2 |
| 1 | Positioning & Mounting | 3 |
| 2 | Installing the PTO & Hyd Pump | 3 |
| 3 | Hydraulic Plumbing | 4 |
| 4 | Product Line Plumbing | 5 |
| 5 | Final Assembly | 6 |
| 6 | Start-Up Procedures | 7 |
| 7 | Operating Procedures | 7 |
| | System Maintenance | 8 |
| | Troubleshooting | 9 |
| | Specifications | 10 |
| | Parts Breakdown | 11 |
| | Parts List | 12 |
| | Product Offering | 13 |
| | Warranty Policy | |

NOTICE

PURCHASER/INSTALLER before proceeding be sure to check the following:

- 1) Do you have a valid CT License? Proceed no further unless you have supplied APSCO with a copy of your CT License.
- 2) This system must be installed and operated in accordance with all DOT regulations and according to the instructions contained inside this manual.
- 3) PURCHASER/INSTALLER must have adequate training on how to operate this system.
- 4) Failure to follow these instructions will void any product warranty and subject the PURCHASER/INSTALLER to any and all potential liabilities associated with this product and/or its use.



INSTALLATION GUIDE, OPERATING PROCEDURES & PARTS BREAKDOWN

Please read this guide carefully before installing and operating the Model 500P THERMAFLOW system.

HYDRAULIC FUNCTION

The Model 500P THERMAFLOW assembly is designed to cool and filter the oil required to operate your hydraulic system by using the product which is being pumped. This is accomplished via a special heat exchanger which is designed to transfer the heat of the hydraulic oil into the product which is being pumped. The amount of heat which is transferred into the product is safely limited only to the amount of cooling which is required. The product supplied to the heat exchanger by a pressure line which is tee'd into the pressure discharge line. APSCO provides an orifice fitting to be installed in the THERMAFLOW unit to limit the amount of product being pumped through the heat exchanger. The exhausting product is then pumped back into the supplying vessel through a suitable port (ex. motor fuel port).

Optional hydraulic controls for this system allow for easy integration with off-truck remote controls for either electric or air shut-offs.

And as with all hydraulic drive systems, this system will also eliminate the need for a driveline. This will reduce maintenance and downtime associated with shaft driven pumps.

TANK STABILIZER FUNCTION

The Model 500P THERMAFLOW is also a tank stabilizer. As the propane is pumped through the heat exchanger it is vaporized. Reintroducing this vaporized product back into the supplying vessel gives the added benefit of maintaining pump performance, reducing pump noise and prolonging pump life.

Because different product pump applications require different speed and power requirements, your THERMAFLOW system was custom engineered for a particular application. If the system is operated beyond its designed capacity, overheating and/or component damage could result.



INSTALLATION GUIDE, OPERATING PROCEDURES & PARTS BREAKDOWN


STEP 1 POSITIONING & MOUNTING

The Model 500P is required to be mounted in a position that meets the DOT's requirements for roll-over-protection. See diagram below for proper mounting bracket and shock mount installation.

NOTE: The THERMAFLOW Model 500P can be mounted either from the rear or bottom mounting holes.

NOTE: Please contact your local DOT representative if you have any questions concerning the DOT's requirements on mounting of equipment that require roll-over-protection.

NOTE: APSCO does not assume any liability for its products if they are mounted or plumbed in a way that does not meet the DOT's requirements.



STEP 2 INSTALLING THE PTO & HYDRAULIC PUMP

A) Install the PTO to the transmission and mount the hydraulic pump according to the instructions included with the PTO.

HELPFUL HINT: *If you are using a direct mount hydraulic pump/PTO combination, be sure that the pump splines are well lubricated with a heavy grease. This grease will prevent premature spline wear on the PTO and pump shafts. A small packet of this grease is available through APSCO. P/N 300980.*



INSTALLATION GUIDE, OPERATING PROCEDURES & PARTS BREAKDOWN

STEP 3 HYDRAULIC PLUMBING

The following diagram shows the proper plumbing for the Model 500P THERMAFLOW assembly. Please carefully read the helpful hint and notes listed below before beginning.

HELPFUL HINT

We recommend the use of 1 1/2" suction hose for all applications, especially if the THERMAFLOW assembly will be operated in cold weather. If the suction hose is too small the hydraulic pump will cavitate and fail prematurely.

NOTE: Be careful not to over tighten NPT threads. It is very easy to crack these types of ports when tightening fittings.




DIAGRAM A

Hydraulic plumbing diagram for THERMAFLOW Model 500P

NOTE: When mounting the THERMAFLOW Model 500P across the frame rails and behind the cab, make sure that the suction and pressure hoses are properly plumbed and secured away from the driveline.



INSTALLATION GUIDE, OPERATING PROCEDURES & PARTS BREAKDOWN

STEP 4 PRODUCT LINE PLUMBING

The following diagram shows the proper product plumbing for the Model 500P THERMAFLOW assembly. Please carefully read the helpful hint and notes listed below before beginning.

NOTE: We have provided the proper orifice fitting installed into the THERMAFLOW cooler assemblies Product Inlet Port. *Failure to use the orifice fitting provided could cause your THERMAFLOW cooler assembly to improperly cool the hydraulic oil. Please consult APSCO. with any questions regarding this orifice fitting.*

NOTE: Always use UP Approved hoses and fittings.




DIAGRAM B

Product plumbing diagram for THERMAFLOW Model 500P



INSTALLATION GUIDE, OPERATING PROCEDURES & PARTS BREAKDOWN


STEP 5 Final Assembly

- A) Complete all hydraulic and product plumbing.
- B) Fill the reservoir until the oil level gets to the top black line on the site level gauge.

NOTE: After the initial start up procedure you will need to add oil due to the hydraulic lines filling up to capacity.

NOTE: Over-filling the reservoir will cause the oil to expand up through the breather assembly when the oil warms up.

NOTE: We recommend using a high grade of hydraulic oil with a Pour Point of -50°F. This will ensure proper oil flow during extreme cold weather operation. Use of synthetic hydraulic oils is also recommended. Recommended Oil: MOBIL DTE 10-32 or equivalent.



***** 500Ps with serial numbers before 1315 utilize element #300331*****

| ITEM NO. | PART NUMBER | DESCRIPTION | QTY. |
|----------|-------------|------------------------|------|
| 1 | 934330ORC | 934330 Cover O-Ring | 1 |
| 2 | 934331 | 934330 Filter Element | 1 |
| 3 | 934330ORE | 934330 Element O-Ring | 1 |
| 4 | 934330OREC | 934330 Canister O-Ring | 1 |
| 5 | 934330ORH | 934330 Head O-Ring | 1 |
| 6 | 934330ORK | 934330 O-Ring Kit | *** |

DIAGRAM C

Filter assembly procedures for THERMAFLOW Model 500P



INSTALLATION GUIDE, OPERATING PROCEDURES & PARTS BREAKDOWN

STEP 6 START-UP PROCEDURES

The following steps are to ensure that the THERMAFLOW assembly is operating properly.

NOTE: Before engaging the PTO, make sure that all hydraulic and product lines are plumbed and properly tightened.

- 1) Connect product hose to proper location so that system can circulate product back into the tank.
- 2) Engage the PTO with engine at idle speed.

NOTE: Watch the oil level in the reservoir. Be ready to add more oil as needed to maintain the oil level between the black and red lines on the site level gauge.

- 3) Check for hydraulic and product leaks and repair as needed.
- 4) Carefully Tach the product pump speed.
- 5) Slowly increase the engine speed until desired product pump speed is obtained.
- 6) Run system for at least five minutes to ensure that system is sufficiently cooling the hydraulic oil. You should see approximately a 10-20°F rise in the hydraulic oil temperature above the product temperature. This oil temperature should then be maintained throughout the entire pumping cycle depending how long the system is run.

NOTE: If the hydraulic oil temperature is higher or lower than the 10-20°F rise, please consult APSCO at 800-334-7699. DO NOT OPERATE THIS SYSTEM UNTIL AFTER YOU HAVE CONSULTED APSCO.

- 7) Slow engine to idle and disengage the PTO.
- 8) System is ready for operation.

STEP 7 OPERATING PROCEDURES

- 1) Engage PTO.
- 2) Set engine speed with the throttle control to the correct RPM.

NOTE: This system is self contained and there is no fan motor to operate.

- 3) To disengage the product pump either disengage any installed control valve or disengage the PTO.



INSTALLATION GUIDE, OPERATING PROCEDURES & PARTS BREAKDOWN

System Maintenance

Hydraulic

Fluid:

- Drain and replace hydraulic oil every 6 to 12 months depending on use.
- Recommended Fluid: Mobil DTE 10-32 or equivalent.

Filter:

- Remove 3 cap screws on top of filter housing.
- Remove filter cartridge and spring.
- Replace with new filter cartridge and spring Part Number 934331 or 300331.
- Apply anti-seize to cap screws and tighten.

Pump:

- Inspect periodically for leaks.
- Check hoses for signs of wear.

Motor:

- Inspect periodically for leaks.
- Check hoses for signs of wear.

PTO

- Grease output shaft every 6 to 12 months depending on use.
- If PTO does not have a grease zerk on output shaft, remove direct mount hydraulic pump and grease the output shaft using a high quality gear lube.



INSTALLATION GUIDE, OPERATING PROCEDURES & PARTS BREAKDOWN

Troubleshooting

Safety First!

Think about it before you do it. Our systems use controlled fluid pressure and converts it to rotational movement. This means that the system pressure operates around 2000 psi. A pin hole leak of fluid at this pressure can be dangerous. Use caution when loosening fittings, system pressure can be maintained for a period of time after shutdown.

Troubleshooting

Always inspect the things easiest to eliminate first. Look for faulty linkage or wiring that controls the PTO, pump or motor. Look at the fluid level and appearance of the oil. Check temperatures and pressures.

Excessive Heat:

- Clean air passages through heat exchanger.
- Check fan operation.
- Check setting of relief valve.
- Check temperature of suction line vs outlet line temperature. If the outlet temperature is noticeably hotter, the pump is cavitating.
- Check for contamination in relief valve. Clean and replace.
- Check for added flow controls. If a flow control has been added to the system, excess heat can be generated by the added restriction to flow.

Loss of Motor Speed:

- Check oil level.
- Ensure recommended engine idle speed is maintained.
- Check output pressure of the pump. If system pressure cannot be maintained, attempt to adjust the relief valve setting to max system pressure. If this does not make a noticeable change, make sure to return relief setting to original position and bring the pump and motor to a hydraulic specialist for bench testing and possible replacement.

Excessive Noise:

- Check oil level. Fill to proper level.
- Ensure use of recommended oil type and weight.
- Ensure suction line to pump is at least 1 1/2".
- Ensure there is no restriction in suction line.

Oil Discoloration:

- Ensure suction line connections are tight.
- Ensure oil is free from water and contaminants. Drain and refill with recommended oil and replace filter.
- Ensure use of recommended oil type and weight.




INSTALLATION GUIDE, OPERATING PROCEDURES & PARTS BREAKDOWN

Specifications

- Max Flow Rate: 25 gpm
- Max Pressure: 3000 psi
- Reservoir: 2.5 gal
- Weight: 50 lbs
- Suction Line: 1.5 Inch
- Pressure Lines: 3/4 Inch
- Warranty: 2 years


Oil - The recommended oil is Mobil DTE 10-32 or equivalent. Mobil DTE 10-32 is a supreme performance anti-wear hydraulic oil engineered for wide temperature range applications. It exhibits optimum flow characteristics at sub-zero temperatures and is resistant to shearing and viscosity loss so that system efficiency is maintained and internal pump leakage is minimized at high operating temperatures and pressures.





INSTALLATION GUIDE, OPERATING PROCEDURES & PARTS BREAKDOWN

MODEL 500P PARTS BREAKDOWN





INSTALLATION GUIDE, OPERATING PROCEDURES & PARTS BREAKDOWN

Parts List

| Item No. | Part # | Description | QTY. |
|----------|--------|---------------------------------|------|
| 1 | 150710 | 16FJIC SWIVEL X16MORB 90° ELBOW | 1 |
| 2 | 150712 | 16MJIC X12MORB 90° ELBOW | 1 |
| 3 | 934330 | FILTER ASSEMBLY | 1 |
| 4 | 300334 | SITE GLASS | 1 |
| 5 | 300412 | 12MORB PLUG | 1 |
| 6 | 300702 | 3000 PSI RELIEF VALVE | 1 |
| 7 | 300708 | 12MJIC-12MORB 90° | 3 |
| 8 | 300748 | 12MORB-12MORB ADJUSTABLE | 1 |
| 9 | 500001 | 500P TANK | 1 |
| 10 | 500030 | 500P LID | 1 |
| 11 | 500032 | SPACER | 4 |
| 12 | 500130 | MOUNTING BRACKET | 2 |
| 13 | 500200 | 500P/100P SHOCK MOUNT | 4 |
| 14 | 500412 | 6MSAE-6MP STRAIGHT | 1 |
| 15 | 500418 | 6MSAE-08MP STRAIGHT | 1 |
| 16 | 600332 | BREATHER | 1 |



INSTALLATION GUIDE, OPERATING PROCEDURES & PARTS BREAKDOWN

Product Offering

Fans

Spal
Multi-Wing

Fittings

Tompkins
Stucci
Ryco

Heat Exchangers

Thermal Transfer
Flat Plate
AKG

Hydraulic Motors

Eaton/Charlynn
Muncie
Permco
Hydro Leduc

PTO's

Muncie

Pumps

Muncie
Parker
Permco
Hydro Leduc



THERMAFLOW WARRANTY

The THERMAFLOW 500P Hydraulic Cooler & Tank Stabilizer is warranted against any defect in material and workmanship which existed at the time of sale by APSCO, Inc. according to the following provisions, subject to the requirements that the Cooler must be used only in accordance with the catalogue and package instructions.

The Cooler is warranted for a period of TWO Years from the date of installation. If during the warranty period the cooler fails to operate to APSCO's specifications due to a defect in any part in material or workmanship that existed at the time of sale by APSCO, the defective part will be repaired or replaced, at APSCO's discretion, at no charge, if the defective part is returned to APSCO. with transportation prepaid.

The above warranty shall terminate if any alterations or repairs are made to the System other than at an authorized dealer or if the cooler is used on any equipment other than the equipment upon which it is first installed.

THE FORGOING WARRANTIES ARE IN LIEU OF ALL OTHER OBLIGATIONS AND LIABILITIES, INCLUDING NEGLIGENCE AND ALL WARRANTIES OF MERCHANTABILITY AND SUITABILITY, EXPRESSED OR IMPLIED AND STATE APSCO'S ENTIRE AND EXCLUSIVE LIABILITY AND BUYER'S EXCLUSIVE REMEDY FOR ANY CLAIM OF DAMAGES IN CONNECTION WITH THE SALE, REPAIR OR REPLACEMENT OF THE ABOVE GOODS, THEIR DESIGN, INSTALLATION OR OPERATION. APSCO. WILL IN NO EVENT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER, AND OUR LIABILITY UNDER NO CIRCUMSTANCES WILL EXCEED THE CONTRACT PRICE FOR THE GOODS FOR WHICH LIABILITY IS CLAIMED.



4221 S. 68th E. Ave., Suite A, Tulsa, OK 74145
800-334-7699 • 763-235-7822 Fax
Web: www.thermaflow.com